

Owner's Manual Multi-Cage Adaptor Kit

For use with the Saraha HP TurboDryer

DRI-EAZ PRODUCTS, INC. 15180 Josh Wilson Road, Burlington, WA 98233 Phone: 800-932-3030 Fax: 360-757-7950 www.dri-eaz.com

READ AND SAVE THESE INSTRUCTIONS

The Multi-Cage Adapter Kit increases the drying capability of the Sahara HD TurboDryer by enabling you to direct air into three cages at one time.

The Adapter Kit includes a snout adapter for the Sahara HD and three 8-foot lengths of 4-inch flexible ducting. Each piece of ducting is fitted with a sliding duct closure and cage hooks designed to attach to virtually any type of cage.

INSTALLATION

1. Press down on the top surface of the Sahara snout, then slide the snout adaptor over it. Push the retaining knobs inward and attach the spring hooks into the Sahara grill.

2. If desired, the ducts may be shortened with scissors and a wire snip. Shorter duct lengths will allow for greater airflow. 3. Attach the ends of the ducting to the cages using the cage hooks. To maximize airflow, route the ducts via the shortest possible route and avoid sharp bends. For best drying results, direct airflow into the lower portion of the cage.

4. Slide the cage attachment closure into the open position before switching the Sahara on. Leaving the doors of unused ducts in the closed position will reduce overall airflow.

Note: This product is designed for use with the Sahara HD TurboDryer. Before operating the Sahara HD, please refer to the Sahara HD Owner's Manual for safety precautions and operating instructions.

Typical Adaptor Kit application

(Airmover and cages purchased separately.)

